

1. Identify all components are present prior to installation.
2. Put waste flange (1) and Rubber washer (2) into the basin hole.
3. Install the Rubber washer (3) and waste body (4), then tighten the waste body.
4. Check all joints and connections for leaks.

1. Waste flange
2. Rubber washer
3. Rubber washer
4. Waste body

