


Assembly Instructions



Assembly Waste Parts

- A. Plug
- B. Nut for adjusting screw
- C. Adjusting screw for plug
- D. Waste flange
- E. Rubber washer
- F. Rubber washer
- G. Waste body
- H. Operating cable
- I. Plastic pipe
- J. Washer
- K. Overflow face
- L. Control knob
- M. Overflow body
- N. Screw
- O. Lock nut

Once assembled, fill the bath with water, check for leaks.

Note: Product is suitable for bathtub thickness 1-10mm.

